

Technical Specification

Single & Double Arm

General Features

This diagram shows the arrangement of the two-arm mounting pole. Spacer tubes and Swing Arm should be installed as per this diagram in order to allow adequate spacing between monitors once installed. Please ensure that the cable manager clip included in the bit bag is installed as shown.

Measurements based on Bolt Through. Desk Clamp Not Available.

